

**YAMAHA**  
**Marine**

# **Outboards**

**2B, 2C  
2U**

**SERVICE  
MANUAL**

## NOTICE

This manual has been prepared by the Yamaha Motor Company primarily for use by Yamaha dealers and their trained mechanics when performing maintenance procedures and repairs to Yamaha equipment. It has been written to suit the needs of persons who have a basic understanding of the mechanical and electrical concepts and procedures inherent in the work, for without such knowledge attempted repairs or service to the equipment could render it unsafe or unfit for use.

Because the Yamaha Motor Company Ltd has a policy of continuously improving its products, models may differ in detail from the descriptions and illustrations given in this publication. Use only the latest edition of this manual. Authorized Yamaha dealers are notified periodically of modifications and significant changes in specifications and procedures, and these are incorporated in successive editions of this manual.

**2B, 2C  
SERVICE MANUAL**

**©1995 Yamaha Motor Co., Ltd.**

**1st Edition, June 1995**

**All rights reserved.**

**No part of this publication may be  
reproduced or transmitted in any form or  
by any means including photocopying and  
recording without the written permission of  
the copyright holder.**

**Such written permission must also be  
obtained before any part of this publication  
is stored in a retrieval system of any nature.**

**Printed in Japan  
P/N 6A1-28197-Z5-11**

## HOW TO USE THIS MANUAL

### MANUAL FORMAT

All of the procedures in this manual are organized in a sequential, step-by-step format. The information has been compiled to provide the mechanic with an easy to read, handy reference that contains comprehensive explanations of all disassembly, repair, assembly, and inspection operations.

In this revised format, the condition of a faulty component will precede an arrow symbol and the course of action required will follow the symbol, e.g.,

- Bearings

Pitting/Damage → Replace.

To assist you to find your way about this manual, the Section Title and Major Heading is given at the head of every page.

An Index to contents is provided on the first page of each Section.

### MODEL INDICATION

Multiple models are shown in this manual. These indications are noted as follows.

Model name	2B	2C
USA and CANADA name	2MH	
Indication	2B	2C

### THE ILLUSTRATIONS

Some illustrations in this manual may differ from the model you have. This is because a procedure described may relate to several models, though only one may be illustrated. (The name of model described will be mentioned in the description).

### REFERENCES

These have been kept to a minimum; however, when you are referred to another section of the manual, you are told the page number to go to.

## **WARNINGS, CAUTIONS AND NOTES**

Attention is drawn to the various Warnings, Cautions and Notes which distinguish important information in this manual in the following ways.

**⚠ The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!**

### **⚠WARNING**

**Failure to follow WARNING instructions could result in severe injury or death to the machine operator, a bystander, or a person inspecting or repairing the outboard motor.**

### **CAUTION:**

**A CAUTION indicates special precautions that must be taken to avoid damage to the outboard motor.**

### **NOTE:**


**A NOTE provides key information to make procedures easier or clearer.**

## HOW TO READ DESCRIPTIONS

1. A disassembly installation job mainly consists of the exploded diagram ①.
2. The numerical figures represented by the number ② indicates the order of the job steps.
3. The symbols represented by the number ③ indicates the contents and notes of the job.  
For the meanings of the symbols, refer to the next page(s).
4. The REMOVAL AND INSTALLATION CHART ④ is attached to the exploded diagram and explains the job steps, part names, notes for the jobs, etc.
5. The SERVICE POINTS, other than the exploded diagram, explains in detail the items difficult to explain in the exploded diagram or REMOVAL AND INSTALLATION CHART, the Service points requiring the detailed description ⑤ ,etc.

**POWR**  **CRANK SHAFT AND PISTON**

**CRANK SHAFT AND PISTON EXPLDED DIAGRAM**



**POWR**  **CRANK SHAFT AND PISTON**

**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
1	CRANK SHAFT AND PISTON REMOVAL	1	Follow the left "Step" for removal.
2	Crank case	1	Refer to "CRANK CASE AND CYLINDER BODY" section in chapter 5. 6 x 20 mm
3	Bolt (with washer)	1	
4	Oil seal housing	1	
5	Plane washer	1	
6	Crankshaft ass'y	1	
7	Circlip	2	
8	Piston pin clip	6	
9	Piston pin	3	NOTE: Remove the crankshaft by lightly tapping it with a plastic hammer.
10	Piston pin washer	6	
11	Small end bearing needle	93	
12	Platon	3	
13	Platon ring	6	
14	Bearing	2	
15	Oil pump drive gear	1	The washer should be placed with their convex sides facing the piston.
16	Spacer	1	Do not a mixture of new and used bearing needles in the same small end.
When installing the bearing, the seal-cap side should be installed towards the flywheel side.			
When installing the gear, the chamfered bore edge side should be installed towards the flywheel side.			
Oil injection model			
Pre-mixed model			
Reverse the removal steps for installation.			
Oil seal housing disassembly			
①	O-ring	1	
②	Oil seal	1	
③	Oil seal	2	

①      ②      ③      ④      ⑤



5-31      5-32

**SYMBOLS**

Symbols ① to ⑨ are designed as thumb-tabs to indicate the content of a chapter.

①	GEN INFO	
②	SPEC	
③	INSP ADJ	
④	FUEL	
⑤	POWR	
⑥	LOWR	
⑦	BRKT	
⑧	ELEC	
⑨	TRBL ANLS	

Symbols ⑩ to ⑯ indicate specific data:

⑩	
⑪	
⑫	
⑬	
⑭	
⑮	
⑯	
⑰	
⑱	
⑲	
⑳	
㉑	
㉒	
㉓	

Symbol ⑯ to ⑯ in an exploded diagram indicate grade of lubricant and location of lubrication point:

㉑	Apply Yamaha 2-stroke outboard motor oil
㉒	Apply Yamaha gear-case lubricant
㉓	Apply molybdenum disulfide oil
㉔	Apply water resistant grease (Yamaha grease A, Yamaha marine grease)

Symbols ㉑ to ㉔ in an exploded diagram indicate grade of sealing or locking agent, and location of application point:

㉑	Apply Gasket Maker®
㉒	Apply LOCTITE® No. 271 (Red LOCTITE)
㉓	Apply LOCTITE® No. 242 (Blue LOCTITE)
㉔	Apply LOCTITE® No. 572

**NOTE: \_\_\_\_\_**

In this manual, the above symbols may not be used in every case.

# INDEX


<b>GENERAL INFORMATION</b>	 GEN INFO	<b>1</b>
<b>SPECIFICATIONS</b>	 SPEC	<b>2</b>
<b>PERIODIC INSPECTION AND ADJUSTMENT</b>	 INSP ADJ	<b>3</b>
<b>FUEL SYSTEM</b>	 FUEL	<b>4</b>
<b>POWER UNIT</b>	 POWR	<b>5</b>
<b>LOWER UNIT</b>	 LOWR	<b>6</b>
<b>BRACKET UNIT</b>	 BRKT	<b>7</b>
<b>ELECTRICAL SYSTEM</b>	 ELEC	<b>8</b>
<b>TROUBLE-ANALYSIS</b>	 TRBL ANLS	<b>9</b>



## CHAPTER 1 GENERAL INFORMATION

**1**

<b>IDENTIFICATION</b> .....	1-1
SERIAL NUMBER .....	1-1
STARTING SERIAL NUMBERS .....	1-1
<b>SAFETY WHILE WORKING</b> .....	1-2
FIRE PREVENTION .....	1-2
VENTILATION .....	1-2
SELF-PROTECTION .....	1-2
OILS, GREASES AND SEALING FLUIDS .....	1-2
GOOD WORKING PRACTICES .....	1-3
DISASSEMBLY AND ASSEMBLY .....	1-4
<b>SPECIAL TOOLS</b> .....	1-5
MEASURING .....	1-6
REMOVAL AND INSTALLATION .....	1-6




## IDENTIFICATION SERIAL NUMBER

The serial number of the outboard motor is stamped on the label attached to the upper part of the swivel bracket.

**NOTE:** \_\_\_\_\_

For USA model:

As an antitheft measure, a special label on which the outboard motor serial number is stamped is bonded to the upper part of the swivel bracket. The label is specially treated so that peeling it off causes cracks across the serial number.



- ① Model name
- ② Approved model No.
- ③ Transom height
- ④ Serial number

## STARTING SERIAL NUMBERS

The starting serial number blocks are as follows:

Model	Approved model No.	STARTING SERIAL No.
2B (2U)	6A1	173765~
2C	6F8	030425~



A70000-0

## SAFETY WHILE WORKING


The procedures given in this manual are those recommended by Yamaha to be followed by Yamaha dealers and their mechanics.



### FIRE PREVENTION

Gasoline (petrol) is highly flammable.

Petroleum vapor is explosive if ignited. Do not smoke while handling petrol, and keep it away from heat, sparks, and open flames.



### VENTILATION

Petroleum vapor is heavier than air and if inhaled in large quantities will not support life. Engine exhaust gases are harmful to breathe. When test-running an engine indoors, maintain good ventilation.



### SELF-PROTECTION

Protect your eyes with suitable safety spectacles or safety goggles when using compressed air, when grinding or when doing any operation which may cause particles to fly off. Protect hands and feet by wearing safety gloves or protective shoes if appropriate to the work you are doing.



### OILS, GREASES AND SEALING FLUIDS

Use only genuine Yamaha oils, greases and sealing fluids or those recommended by Yamaha.



Under normal conditions of use, there should be no hazards from the use of the lubricants mentioned in this manual, but safety is all-important, and by adopting good safety practises, any risk is minimized.

A summary of the most important precautions is as follows:

1. While working, maintain good standards of personal and industrial hygiene.
2. Clothing which has become contaminated with lubricants should be changed as soon as practicable, and laundered before further use.
3. Avoid skin contact with lubricants; do not, for example, place a soiled wiping-rag in one's pocket.
4. Hands, and any other part of the body which have been in contact with lubricants or lubricant-contaminated clothing, should be thoroughly washed with hot water and soap as soon as practicable.
5. To protect the skin, the application of a suitable barrier cream to the hands before working is recommended.
6. A supply of clean lint-free cloths should be available for wiping purposes.



## GOOD WORKING PRACTICES

### 1. The right tools

Use the special tools that are advised to protect parts from damage. Use the right tool in the right manner- don't improvise.

### 2. Tightening torque


Follow the torque tightening instructions. When tightening bolts, nuts and screws, tighten the larger sizes first, and tighten inner-positioned fixings before outer-positioned ones.

**3. Non-reusable items**

Always use new gaskets, packing, O-rings, split-pins and circlips etc. on reassembly.

**DISASSEMBLY AND ASSEMBLY**

1. Clean parts with compressed-air on disassembling them.
2. Oil the contact surfaces of moving parts on assembly.



3. After assembly, check that moving parts operate normally.

4. Install bearings with the manufacturer's markings on the side exposed to view, and liberally oil the bearings.
5. When installing oil seals, apply a light coating of water-resistant grease to the outside diameter.




A80701-0\*

## SPECIAL TOOLS

The use of correct special tools recommended by Yamaha will aid the work and enable accurate assembly and tune-up. Improvisations and use of improper tools can cause damage to the equipment.

### NOTE: \_\_\_\_\_

- For U.S.A. and Canada, use part number starting with "YB-", "YU-" or "YW-".
- For others, use part number starting with "90890-".





## MEASURING

	Tool name	Tool No.		Use for :
		USA and Canada (a)	Except for USA and Canada (b)	
1	Tachometer	YU-08036-A	90890-06760	Idle speed
2	Dynamic spark tester	YM-34487	90890-06754	Ignition system
3	Pressure tester	YB-35956	90890-06762	Lower case
4	Dial indicator	YU-03097	90890-01252	Backlash
5	Backlash indicator	YB-06265	90890-06265	Backlash
6	Magnetic flexible stand	YU-34481	90890-06705	Backlash
7	Backlash adjusting plate	YB-07003	N.A.	Backlash
8	Thickness gauge	YU-26900-9	N.A.	Shimming
9	Digital multimeter	YU-34899-A	90890-06752	Electrical
10	Pocket tester	YU-03112	90890-03112	Electrical

## REMOVAL AND INSTALLATION

	Tool name	Tool No.		Use for :
		USA and Canada (a)	Except for USA and Canada (b)	
11	Bearing separator	YB-06219	90890-06534	Crank shaft bearing
12	Flywheel holder	YB-06139	90890-06522	Flywheel
13	Flywheel puller	YB-06117	90890-06521	Flywheel
14	Stopper guide plate	N.A.	90890-06501	Forward gear bearing
15	Bearing outer race puller clow	N.A.	90890-06535	Forward gear bearing
16	Stopper guide stand	N.A.	90890-06538	Forward gear bearing
17	Slide hammer set	YB-06096	N.A.	Forward gear bearing
18	Bearing installer	YB-06014	90890-06638	Forward gear bearing
19	Driver rod - S	N.A.	90890-06606	Forward gear bearing
20	Drive shaft bushing remover	YB-06027	90890-06651	Drive shaft bushing
21	Bushing installer	YB-06029	90890-06601	Drive shaft bushing
22	Needle bearing installer	YB-06169	N.A.	Drive shaft bushing
23	Driver rod - L	YB-06071	90890-06605	Drive shaft bushing
24	Driver rod - M10	YB-06229	90890-06652	Forward gear bearing
				Drive shaft bushing



## CHAPTER 2 SPECIFICATIONS

**GENERAL SPECIFICATIONS** ..... 2-1

**MAINTENANCE SPECIFICATIONS** ..... 2-3

  ENGINE ..... 2-3

  LOWER ..... 2-4

  ELECTRICAL ..... 2-5

  DIMENSION ..... 2-5

**TIGHTENING TORQUE** ..... 2-6

  SPECIFIED TORQUE ..... 2-6

  GENERAL TORQUE ..... 2-6

## GENERAL SPECIFICATIONS

Item	Unit	Model	
		2B	2C
Approved model No.		6A1	6F8
<b>DIMENSION:</b>			
Over-all length	mm (in)	607 (23.9)	
Over-all width	mm (in)	214 (8.4)	
Over-all height	mm (in)	916 (36.1)	
Boat transom height	mm (in)	381 (15.0)	
<b>WEIGHT:</b>			
Weight (PL)	kg (lb)	10 (22.0)	9.8 (21.6)
<b>PERFORMANCE:</b>			
Output (ISO)	kW (hp) / rpm	1.5 (2) / 4500	
Full throttle operating range	rpm	4000~5000	
Maximum fuel consumption	L (US gal, Imp gal)/h at rpm	1.3 (0.34,0.29) at 5000	1.4 (0.37,0.31) at 5000
<b>ENGINE:</b>			
Type		2 stroke	
Number of cylinder		1	
Bore X Stroke	mm (in)	39.0 x 36.0 (1.54 x 1.42)	42.0 x 36.0 (1.65 x 1.42)
Total displacement	cm <sup>3</sup> (cu.in)	43 (2.62)	50 (3.05)
Compression ratio		7.40	8.30
Number of carburetor		1	
Intake system		Reed valve	
Scavenging system		Loop charge	
Control system		Tiller control	
Starting system		Manual	
Ignition system		CDI	
Enrichment system		Choke valve	
Advance type		Fixed	
Spark plug (NGK)		B5HS	B7HS
for CANADA and Europe		BR5HS	—
Exhaust system		Under water	
Cooling system		Water	
Lubrication system		Pre-mixed fuel & Oil	

Item	Unit	Model	
		2B	2C
<b>FUEL AND LUBRICATION:</b>			
Fuel type			Reguler gasoline
Fuel tank capacity	L (US gal, Imp gal)		1.2 (0.32,0.26)
Engine oil type / Grade			TC-W3
Gear oil type			2-Stroke outboard motor oil / TC-W3
Gear oil quantity	cm <sup>3</sup> (US oz, Imp oz)		45 (1.52,1.58)
Mixing ratio			100:1(GEN 50:1)
<b>BRACKET:</b>			
Tilt Angle	degree		4,8,12,16
Tilt-up Angle	degree		73
Steering Angle	degree		360
<b>DRIVE UNIT:</b>			
Gear Shift Position			Forword
Gear Ratio			2.08 (27/13)
Gear Type			Zerol gear
Clutch Type			NA
Propeller Direction			Clockwise
Propeller Drive System			Shear Pin
Propeller Series Mark			A

# MAINTENANCE SPECIFICATIONS

## ENGINE

Item	Unit	Model	
		2B	2C
<b>CYLINDER HEAD:</b>			
Warpage limit	mm (in)	0.1 (0.004)	
<b>CYLINDER:</b>			
Bore size	mm (in)	39.00~39.02 (1.535~1.536)	42.00~42.02 (1.654~1.654)
Wear limit	mm (in)	39.10 (1.54)	42.10 (1.66)
Taper limit	mm (in)	0.08 (0.003)	
Out of round limit	mm (in)	0.05 (0.002)	
<b>PISTON:</b>			
Piston clearance	mm (in)	0.030~0.035 (0.0012~0.0014)	
Limit	mm (in)	0.085 (0.0033)	
Diameter	mm (in)	38.967~38.986 (1.5341~1.5349)	41.970~42.000 (1.6524~1.6535)
Measuring point H	mm (in)	10 (0.39)	
Pin boss inside diameter	mm (in)	10.004 ~ 10.015 (0.3939 ~ 0.3943)	
Ring groove clearance Top	mm (in)	0.03~0.07 (0.001~0.003)	0.02~0.06 (0.001~0.002)
Ring groove clearance 2nd	mm (in)	0.03~0.07 (0.001~0.003)	
Over size diameter 1st*	mm (in)	39.25 (1.545)	42.25 (1.663)
Over size diameter 2nd	mm (in)	39.50 (1.555)	42.50 (1.673)
<b>PISTON PIN:</b>			
Diameter	mm (in)	9.996~10.000 (0.3935~0.3937)	
<b>PISTON RING (TOP):</b>			
Type		Plain	Keystone
Dimensions (B x T)	mm (in)	2.0x1.8 (0.08x0.07)	
End gap (Installed)	mm (in)	0.10~0.30 (0.004~0.012)	
Limit	mm (in)	0.50 (0.020)	
<b>PISTON RING (2nd):</b>			
Type		Plain	Barrel
Dimensions (B x T)	mm (in)	2.0x1.8 (0.08x0.07)	
End gap (Installed)	mm (in)	0.10~0.30 (0.004~0.012)	
Limit	mm (in)	0.50 (0.020)	
<b>CONNECTING ROD:</b>			
Small end diameter	mm (in)	14.000~14.011 (0.5512~0.5516)	
<b>CRANK SHAFT ASSEMBLY:</b>			
Crank width A	mm (in)	27.90~27.95 (1.098~1.100)	
Runout limit D	mm (in)	0.02 (0.001)	
Big end side clearance E	mm (in)	0.30~0.60 (0.012~0.024)	
Small end axial play limit F	mm (in)	2.0 (0.08)	
<b>REED VALVE:</b>			
Valve stopper height	mm (in)	6.0±0.2 (0.24±0.01)	
Valve warpage limit	mm (in)	0.3 (0.01)	

\*:Except for U.S.A.

**SPEC****MAINTENANCE SPECIFICATIONS****E**

Item	Unit	Model	
		2B	2C
<b>CARBURETOR:</b>			
Identification mark		6A103	6F803
Float height	mm (in)	17.3±0.5 (0.68±0.02)	
Valve seat size	mm (in)	1.4 (0.06)	
Main jet (M.J.)	#	96	104
Jet needle (J.N.)	#	167	166
Cut away (C.A.)	#	0.75	
<b>ENGINE SPEED:</b>			
Idle speed	rpm	1,150±50	
<b>RECOIL STARTER:</b>			
Starter rope length	mm (in)	1,300± (51.2)	

**LOWER**

Item	Unit	Model	
		2B	2C
<b>GEAR BACKLASH:</b>			
Pinion - Forward (S.S.T.)	mm	0.27~0.99	
Pinion shims	mm	0.3, 0.4, 0.5	
Propeller size (Aluminium)		3 x 7-1/4 x 4-1/2	
		3 x 7-1/4 x 5-1/2	3 x 7-1/4 x 5
		-	3 x 7-1/4 x 5-1/2
Propeller size (Plastic)		3 x 7-1/4 x 4	
Test propeller 1	rpm	90890-01601, YB-1601	4,400~4,700

## ELECTRICAL

Item	Unit	Model			
		2B	2C		
IGNITION TIMING:					
Ignition timing (full advanced)	Degree	B.T.D.C. 18±2			
Piston position (full advanced)	mm (in)	B.T.D.C. 1.11 +0.26 -0.23 (0.044 +0.010 -0.009)			
STATOR ASSEMBLY:					
Charge coil resistance	Ω (color)	316.8~387.2 (Brown-Earth)			
Pole number		4			
CDI UNIT:		Unit: kΩ			
		W	B	Br	O
	W		•	∞	•
	B	2.2~9.5		2.2~9.5	•
	Br	∞	•		•
	O	7~30	2~9	7~30	


**NOTE:**

- The resistance values will vary from meter to meter, especially with electronic digital meters. For some testers, polarity of leads is reversed.
- “•” indicates that the pointer deflects once and returns to specification.
- “∞” mark indicates discontinuity.

IGNITION COIL:		
Type (single / twin)		Single
Primary coil resistance	Ω (color)	0.18~0.24 (Orange-Black)
Secondarily coil resistance	kΩ (color)	2.7~3.7 (Black/White-High tension cord)
SPARK PLUG CAP:		
Type		Standard
Type (for Canada and Europe)		Resistance
SPARK PLUG:		
Gap	mm (in)	0.6~0.7 (0.024~0.028)

## DIMENSION

Item	Unit	Model	
		2B	2C
H4	mm (in)	417 (16.4)	
B13	mm (in)	100 (3.9)	
B14	mm (in)	95 (3.7)	
C1	mm (in)	23 (0.9)	
C2	mm (in)	60 (2.4)	





## TIGHTENING TORQUE


### SPECIFIED TORQUE

Part to tightened	Part name	Thread size	Q'ty	Tightening torque			Remarks
				Nm	m•Kg	ft•lb	
<b>ENGINE:</b>							
Flywheel magneto	Nut	M10	1	45	4.5	32	→ E
Intake manifold	1st	Bolt	M6	4	5	0.5	3.6
	2nd				10	1.0	7.2
Reed valve	Bolt	M4	2	1	0.1	0.7	
Spark plug	Bolt	M14	1	25	2.5	18	
Cylinder head	1st	Bolt	M6	4	5	0.5	3.6
	2nd				10	1.0	7.2
Crankcase	1st	Bolt	M6	2	5	0.5	3.6
	2nd				10	1.0	7.2
<b>BRACKET:</b>							
Clamp bracket	Nut	M8	1	16	1.6	11	

Nut A	Bolt B	General torque specifications		
		Nm	m•kg	ft•lb
8 mm	M5	5.0	0.5	3.6
10 mm	M6	8.0	0.8	5.8
12 mm	M8	18	1.8	13
14 mm	M10	36	3.6	25
17 mm	M12	43	4.3	31

## GENERAL TORQUE

This chart specifies the torques for tightening standard fasteners with standard clean dry ISO threads at room temperature. Torque specifications for special components or assemblies are given in applicable sections of this manual. To avoid causing warpage, tighten multifastener assemblies in criss-cross fashion, in progressive stages until the specified torque is reached.





## CHAPTER 3

### PERIODIC INSPECTION AND ADJUSTMENT

MAINTENANCE INTERVAL CHART .....	3-1
<b>PERIODIC SERVICE .....</b>	<b>3-2</b>
CONTROL SYSTEM .....	3-2
Idle speed adjustment .....	3-2
LOWER UNIT .....	3-2
Gear oil .....	3-2
Lower unit leakage check .....	3-3
GENERAL .....	3-4
Anode .....	3-4
Spark plug .....	3-4
Grease points .....	3-5

**INSP  
ADJ****MAINTENANCE INTERVAL CHART****E****MAINTENANCE INTERVAL CHART**

The following chart should be considered strictly as a guide to general maintenance intervals. Depending on operating conditions, the intervals of maintenance should be changed.

Item	Remarks	Initial		Every		Refer page
		10 hours (Break-in)	50 hours (3 months)	100 hours (6 months)	200 hours (1 year)	
<b>FUEL SYSTEM:</b>						
Fuel hose	Inspection			O		4-2
Fuel tank	Cleaning			O	O	4-2
Fuel cock filter element	Cleaning			O	O	4-2
Carburetor	Cleaning	O	O	O		4-7
<b>POWER UNIT:</b>						
Water leakage	Inspection		O	O		-
Motor exterior	Inspection		O	O		-
Exhaust leakage	Inspection	O	O	O		-
Cooling water passage	Cleaning		O	O		-
<b>CONTROL SYSTEM:</b>						
Idle speed	Inspection/Adjustment			O		3-2
<b>LOWER UNIT:</b>						
Gear oil	Change	O		O		3-2
Lower unit leakage	Inspection				O	3-3
Cotter pin and shear pin	Inspection		O	O		6-2
Propeller	Inspection		O	O		6-2
<b>GENERAL:</b>						
Anode	Inspection	O	O	O		3-4
Spark plug	Cleaning / Adjustment Replacement	O	O	O		3-4
Wiring and connector	Adjustment/Reconnect	O	O	O		-
Bolts and nuts	Retightening	O		O		-
Grease points	Greasing			O		3-5



## PERIODIC SERVICE CONTROL SYSTEM

### Idle speed adjustment

#### 1. Measure:

- Idle speed

Out of specification → Adjust.



**Idle speed:**  
 $1,150 \pm 50$  rpm

### Measuring steps:

- Start the engine and allow it to warm up for a few minutes.
- Attach the tachometer to the high tension lead.



**Tachometer:**  
YU-08036-A/90890-06760

#### 2. Adjust:

- Idle speed

### Adjustment steps:

- Start the engine and allow it to warm up for a few minutes.
- Attach the tachometer to the high tension lead.




**Tachometer:**  
YU-08036-A/90890-06760

- Adjust the idle adjusting screw ① in or out until specified idle speed is obtained.

Turning in → Idle speed becomes higher.

Turning out → Idle speed becomes lower.



## LOWER UNIT

### Gear oil

#### 1. Check:

- Gear oil

Milky oil → Replace the oil seal.

Slag oil → Check the gear, bearing and dog.


## 2. Check:

- Gear oil level

Oil level is low → Add oil to proper level.

## 3. Replace:

- Gear oil

**Replacement steps:**

- Place the outboard motor in an upright position.
- Place a pan under the drain plug.
- Remove the drain plug ①, then the oil level plug ② and drain the oil thoroughly.
- Fill the gear oil through the drain hole until it overflows at the level hole.

**Recommended oil:**


GEAR CASE LUBE (USA) or

Hypoid gear oil, SAE #90

**Oil capacity:**

45 cm<sup>3</sup> (1.52 US oz, 1.58 Imp oz)

- Refit the oil level plug and then oil drain plug.

**Lower unit leakage check**

## 1. Check:

- Pressure holding

Pressure falls → Inspect seals and component parts.

**Checking steps:**

- Attach the tester to the oil-level hole.

**Pressure tester:**

YB-03595/90890-06762

- Apply the specified pressure.


**Pressure:**

100 kPa (1.0 kg/cm<sup>2</sup>, 14.2 psi)

- Check that the pressure is held at the specified pressure for 10 seconds.

**CAUTION:**

**Do not over-pressurize. Excess pressure may cause the air to leak out.**



## GENERAL


### Anode

#### 1. Inspect:

- Anode
- Scale → Clean
- Oil/grease → Clean
- Corrosion → Replace

### CAUTION:

**Do not oil, grease or paint the anode, or the function of the sacrificial anode will be spoiled.**



### Spark plug

#### 1. Inspect:

- Electrode ①
- Wear/Damage → Replace
- Insulator color ②
- Distinctly different color → Check the engine condition



#### Color guide:

##### Normal:

Medium to light tan color

##### Whitish color:

- Lean fuel mixture
- Plugged fuel mixture
- Air leak
- Wrong setting

##### Blackish color:

- Electrical malfunction
- Defective spark plug
- Defective ignition system
- Rich mixture
- Excessive idling

#### 2. Clean:

##### • Spark plug

Clean the spark plug with a plug cleaner or wire brush.



## 3. Inspect:

- Spark plug type




**Standard spark plug:**  
2B : B5HS  
For CANADA and Europe:  
BR5HS  
2C : B7HS

## 4. Measure:

- Electrodes gap ②
- Out of specification → Regap.



**Gap:**  
0.6 ~ 0.7 mm (0.024 ~ 0.028 in)



## 5. Tighten:


- Spark plug

## NOTE: \_\_\_\_\_

Before installing the spark plug, clean the gasket surface and the plug surface.



**Spark plug:**  
25Nm (2.5m·kg, 18ft·lb)



377-004


## NOTE: \_\_\_\_\_

If a torque wrench is not available, a good estimate of the correct torque is a further 1/4 to 1/2 turns ② on finger-tightened ① spark plug.

## Grease points

## 1. Apply:


- Water resistant grease





## CHAPTER 4 FUEL SYSTEM

<b>FUEL TANK AND FUEL COCK .....</b>	4-1
EXPLODED DIAGRAM .....	4-1
REMOVAL AND INSTALLATION CHART .....	4-2
SERVICE POINTS .....	4-2
Fuel hose inspection .....	4-2
Fuel tank inspection .....	4-2
Fuel cock inspection .....	4-2
<b>CARBURETOR REMOVAL .....</b>	4-3
EXPLODED DIAGRAM .....	4-3
REMOVAL AND INSTALLATION CHART .....	4-4
<b>CARBURETOR .....</b>	4-5
EXPLODED DIAGRAM .....	4-5
REMOVAL AND INSTALLATION CHART .....	4-6
SERVICE POINTS .....	4-7
Carburetor inspection .....	4-7

**FUEL TANK AND FUEL COCK  
EXPLODED DIAGRAM**



## REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	<b>FUEL TANK AND FUEL COCK</b>		Follow the left "Step" for removal.
	<b>REMOVAL</b>		
1	Screw	2	
2	Screw (with washer)	2	6 x 25 mm
3	Screw (with washer)	2	6 x 40 mm
4	Screw (with washer)	4	5 x 10 mm
5	Plug cap cover	1	
6	Apron (left)	1	
7	Apron (right)	1	
8	Bolt (with washer)	3	6 x 16 mm
9	Recoil starter assembly	1	
10	Clip	2	
11	Fuel hose (fuel cock - carburetor)	1	
12	Nut	2	
13	Spring washer	2	
14	Plain washer	2	
15	Bolt	2	6 x 18 mm
16	Fuel tank assembly	1	
17	Grommet	1	
18	Fuel cock	1	
Reverse the removal steps for installation.			

## SERVICE POINTS

## Fuel hose inspection

## 1. Inspect:

•Fuel hose

Crack/Leak/Damage → Replace.

Clog → Clean.

## Fuel tank inspection

## 1. Inspect:

•Fuel tank

•Fuel tank cap

Crack/Leak/Damage → Replace.

Dirt → Clean.




## Fuel cock inspection

## 1. Inspect:

•Fuel cock filter element

Crack/Leak → Replace.


Clog → Clean.

**CARBURETOR REMOVAL  
EXPLODED DIAGRAM**



## REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	<b>CARBURETOR REMOVAL</b>		Follow the left "Step" for removal. Refer to "FUEL TANK AND FUEL COCK".
1	Apron	1	
2	Stop switch lead (white)	1	
3	Screw	1	5 x 8 mm
4	Ground lead (black)	1	
5	Clip	1	
6	Fuel hose (fuel cock - carburetor)	1	
7	Screw	1	
8	Carburetor assembly	1	
9	Screw	1	
10	Throttle lever knob	1	
11	Screw	2	4 x 35 mm
12	Silencer cover assembly	1	
13	Chock knob	1	
14	O-ring	1	
15	Screw	1	5 x 25 mm
16	Spring	1	
17	Plate	1	
18	Circlip	1	
19	Pin	1	
20	Acceleration arm	1	
21	Bolt (with washer)	1	5 x 10 mm
22	Throttle lever link	1	
	Carburetor assembly	1	
<b>SILENCER COVER DISASSEMBLY</b>			
①	Nut	1	
②	Ground lead	1	
③	Stop switch	1	
④	Bracket	1	
⑤	Silencer cover	1	
			Reverse the removal steps for installation.

**CARBURETOR  
EXPLODED DIAGRAM**



## REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	<b>CARBURETOR DISASSEMBLY</b>		Follow the left "Step" for removal. Refer to "CARBURETOR REMOVAL".
1	Carburetor assembly		
1	Screw	1	
2	Clamp	1	
3	Nut	1	
4	Spring washer	1	
5	Plane washer	1	
6	Choke valve shaft	1	
7	Choke valve	1	
8	Drain screw	1	
9	Gasket	1	
10	Throttle screw	1	<b>NOTE:</b> <u>Loosen the throttle screw.</u>
11	Mixing chamber screw	1	
12	Throttle bar barrel	1	
13	Throttle valve	1	
14	Spring seat	1	
15	Spring	1	
16	Jet needle	1	
17	Circlip	1	
18	Throttle screw	1	
19	Throttle link bracket	1	
20	Cap	1	
21	Throttle bar	1	
22	Spacer	1	
23	Screw	2	
24	Float chamber	1	
25	Float chamber gasket	1	
26	Screw	1	
27	Float	1	
28	Float pin	1	
29	Needle valve	1	
30	Main jet	1	
31	Main nozzle	1	
32	Idle adjusting screw	1	
33	Spring	1	
34	Carburetor body	1	
35	O-ring	1	
Reverse the removal steps for installation.			



## SERVICE POINTS

### CAUTION:

**Do not use steel wire for cleaning the jets as this may enlarge the jet diameters and seriously affect performance.**

### Carburetor inspection

#### 1. Inspect:

- Carburetor body  
Crack/Damage → Replace.  
Contamination → Clean.

#### 2. Inspect:

- Jet needle  
Bend/Wear → Replace.

#### 3. Inspect:



- Main jet
- Main nozzle  
Contamination → Clean.

#### 4. Inspect:

- Needle valve  
Grooved wear → Replace.

#### 5. Inspect:

- Float  
Crack/Damage → Replace.



#### 6. Measure:

##### •Float height ②

Out of specification → Fold the tab ② to adjust float arm height.



##### Float height:

**$17.3 \pm 0.5 \text{ mm (} 0.68 \pm 0.02 \text{ in)}$**

#### NOTE:


- The float should be resting on the needle valve, but not compressing the needle valve.
- Take measurement at the end surface of the float opposite to its pivoted side.

## CHAPTER 5 POWER UNIT

<b>POWER UNIT REMOVAL</b> .....	5-1
EXPLDED DIAGRAM .....	5-1
REMOVAL AND INSTALLATION CHART .....	5-2
 <b>RECOIL STARTER</b> .....	5-3
EXPLDED DIAGRAM .....	5-3
REMOVAL AND INSTALLATION CHART .....	5-4
SERVICE POINTS .....	5-4
Sheave drum removal .....	5-4
Spiral spring removal .....	5-5
Drive plate inspection .....	5-5
Drive pawl and spring inspection .....	5-5
Sheave drum inspection .....	5-5
Spiral spring inspection .....	5-5
Starter rope inspection .....	5-6
Starter rope installation .....	5-6
Sheave drum installation .....	5-6
Spiral spring setting .....	5-6
Recoil starter checking .....	5-6
 <b>FLYWHEEL MAGNETO AND MAGNETO BASE</b> .....	5-7
EXPLDED DIAGRAM .....	5-7
REMOVAL AND INSTALLATION CHART .....	5-8
SERVICE POINTS .....	5-8
Flywheel magneto removal .....	5-8
 <b>ELECTRICAL UNIT</b> .....	5-10
EXPLDED DIAGRAM .....	5-10
REMOVAL AND INSTALLATION CHART .....	5-11
 <b>REED VALVE</b> .....	5-12
EXPLDED DIAGRAM .....	5-12
REMOVAL AND INSTALLATION CHART .....	5-13
SERVICE POINTS .....	5-13
Reed valve inspection .....	5-13





<b>CYLINDER HEAD</b> .....	5-14
EXPLODED DIAGRAM .....	5-14
REMOVAL AND INSTALLATION CHART .....	5-15
SERVICE POINTS .....	5-15
Cylinder head inspection .....	5-15
 <b>CRANKCASE AND CYLINDER BODY</b> .....	5-16
EXPLODED DIAGRAM .....	5-16
REMOVAL AND INSTALLATION CHART .....	5-17
SERVICE POINTS .....	5-17
Cylinder body inspection .....	5-17
Piston to cylinder clearance .....	5-18
Cylinder body and crankcase installation .....	5-19
 <b>CRANKSHAFT AND PISTON</b> .....	5-20
EXPLODED DIAGRAM .....	5-20
REMOVAL AND INSTALLATION CHART .....	5-21
SERVICE POINTS .....	5-21
Bearing removal .....	5-21
Piston inspection .....	5-22
Piston pin and small end bearing inspection .....	5-22
Piston ring inspection .....	5-23
Crankshaft inspection .....	5-24
Piston and piston ring installation .....	5-25

**POWER UNIT REMOVAL  
EXPLODED DIAGRAM**



## REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	<b>POWER UNIT REMOVAL</b>		Follow the left "Step" for removal.
1	Apron		Refer to "FUEL TANK AND FUEL COCK" section in chapter 4.
1	Bolt (with washer)	6	6 x 25 mm <b>NOTE:</b> _____
2	Engine unit	1	Tighten the bolts in two steps of torque. <b>NOTE:</b> _____
3	Dowel pin	2	Film-coat the exhaust guide mating surface with Gasket Maker or equivalent. _____
4	Upper case gasket	1	Reverse the removal steps for installation.

RECOIL STARTER  
EXPLODED DIAGRAM



## REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	<b>RECOIL STARTER DISASSEMBLY</b>		Follow the left "Step" for removal. Refer to "FUEL TANK AND FUEL COCK" section in chapter 4.
1	Bolt	1	
2	Drive plate	1	
3	Drive pawl spring	1	
4	Drive pawl	1	
5	Spring	1	
6	Sheave drum	1	
7	Spiral spring	1	<b>NOTE:</b> •When installing the new spiral spring, do not cut the wire holding the spring. •When reusing the spiral spring, set the leading end first in the case and then fit one turn each time.
8	Starter handle	1	
9	Rope	1	1,300 mm
10	Starter case	1	Reverse the removal steps for installation.

## SERVICE POINTS

## Sheave drum removal


## 1. Turn:


- Sheave drum

Turn the sheave drum clockwise until the spiral spring is free.

**NOTE:**

- Turn the sheave drum so that the cutaway on the outer surface of the sheave drum faces toward the starter handle.
- Pass the starter rope through the cut.





2. Remove:


- Sheave drum

**⚠ WARNING**

When removing the sheave drum, be sure to turn the sheave drum upside down to prevent the spiral spring from popping up at you.

**NOTE:**

Insert a standard screwdriver into the hole in the sheave drum, and remove the spiral spring from the sheave drum by pushing the spring.



**Spiral spring removal**

1. Remove:

- Spiral spring

**⚠ WARNING**

Be careful so that the spiral spring does not pop out when removing it. Remove it by allowing it out one turn of the winding each time.

**Drive plate inspection**

1. Inspect:

- Drive plate
- Crack/Damage → Replace.

**Drive pawl and spring inspection**

1. Inspect:

- Drive pawl
- Crack/Wear/Damage → Replace.
- Drive pawl spring
- Broken/Bent/Damage → Replace.

**Sheave drum inspection**

1. Inspect:

- Sheave drum
- Crack/Damage → Replace.

**Spiral spring inspection**

1. Inspect:

- Spiral spring
- Broken/Bent/Damage → Replace.



### Starter rope inspection

1. Inspect:

- Starter rope

Fray/Wear/Damage → Replace.

**NOTE:**

When replacing the rope, cut it to the specified length and burn the rope end to prevent the end from being frayed.



**Starter rope length:**

1,300 mm (51.2 in)


### Starter rope installation

1. Install:

- Starter rope

**NOTE:**

- Insert the rope through the rope holes and knot the end.
- Wind the rope 3-1/2 turns around the sheave drum.
- Place the rope at the cutaway.




### Sheave drum installation

1. Install:

- Sheave drum
- Spiral spring

**NOTE:**

Position the inner end of the spiral spring on the retainer post of the sheave drum.




### Spiral spring setting

1. Set:

- Spiral spring

**NOTE:**

Wind up the spring 3 turns counterclockwise with the starter rope.




### Recoil starter checking

1. Check:

- Starter operation


Unsmooth operation → Repair.

**FLYWHEEL MAGNETO AND MAGNETO BASE  
EXPLODED DIAGRAM**



## REMOVAL AND INSTALLATION CHART



Step	Procedure/Part name	Q'ty	Service points
	<b>FLYWHEEL MAGNETO AND MAGNETO BASE REMOVAL</b>		Follow the left "Step" for removal.
	Recoil starter assembly		Refer to "FUEL TANK AND FUEL COCK" section in chapter 4.
1	Screw	3	6 x 12 mm
2	Starter pulley	1	
3	Hole cover	1	
4	Flywheel nut	1	
5	Washer	1	
6	Flywheel magneto	1	
7	Woodruff key	1	
8	Bolt	2	
9	Base assembly	1	
	<b>MAGNETO BASE DISASSEMBLY</b>		
①	Screw	2	5 x 20 mm
②	Charge coil	1	
③	Base plate	1	
			Reverse the removal steps for installation.



### SERVICE POINTS

#### Flywheel magneto removal


1. Remove:
  - Flywheel nut



A For USA and Canada  
 B Except for USA and Canada

**CAUTION:**

The major load should be carried in the direction of the arrows. If not, the holder may easily slip off.



## 2. Remove:


- Flywheel magneto

**Flywheel puller:**

YB-06117 / 90890-06521

**A** For USA and Canada**B** Except for USA and Canada**CAUTION:**

To prevent damage to the engine or tools, screw in the flywheel magneto- puller set-bolts evenly and completely so that the puller plate is parallel to the flywheel.





POWR



## FLYWHEEL MAGNETO AND MAGNETO BASE

E

**ELECTRICAL UNIT  
EXPLODED DIAGRAM**




## ELECTRICAL UNIT



E

### REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	<b>ELECTRICAL UNIT REMOVAL</b>		Follow the left "Step" for removal. Refer to "FUEL TANK AND FUEL COCK" section in chapter 4.
1	Clamp	1	Pink and black leads
2	Spark plug cap	1	
3	Bolt (with washer)	1	6 x 20 mm
4	Ignition coil	1	
5	Charge coil lead (brown)	1	
6	Stop switch lead (white)	1	
7	Screw	1	5 x 8 mm
8	Ground lead (black)	1	
9	Bolt (with washer)	1	
10	CDI unit	1	
			Reverse the removal steps for installation.




## REED VALVE EXPLODED DIAGRAM





## REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	<b>REED VALVE REMOVAL</b>		Follow the left "Step" for removal.
	Recoil starter assembly		Refer to "FUEL TANK AND FUEL COCK" section in chapter 4.
	Carburetor assembly		Refer to "CARBURETOR REMOVAL" section in chapter 4.
1	Bolt	4	<b>NOTE:</b> Tighten the bolts in sequence and in two steps of torque.
2	Stay	1	
3	Reed valve assembly	1	
4	Reed valve gasket	1	
	<b>REED VALVE DISASSEMBLY</b>		
①	Screw (with washer)	2	
②	Valve stopper	1	
③	Reed valve	1	
④	Reed valve body	1	
			Reverse the removal steps for installation.



## SERVICE POINTS



## Reed valve inspection

## 1. Inspect:

- Reed valve
- Crack/Damage → Replace.


## 2. Measure:

- Valve warpage ①
- Out of specification → Replace.





## 3. Measure:

- Valve stopper height ②
- Out of specification → Replace.



## **CYLINDER HEAD EXPLODED DIAGRAM**





## REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	<b>CYLINDER HEAD REMOVAL</b>		Follow the left "Step" for removal.
	Fuel tank		Refer to "FUEL TANK AND FUEL COCK" section in chapter 4.
1	Bolt (with washer)	2	6 x 10 mm
2	Fuel tank protector	1	
3	Spark plug cap	1	
4	Spark plug	1	
5	Bolt (with washer)	4	6 x 25 mm
6	Cylinder head	1	<b>NOTE:</b> Tighten the bolts in sequence and in two steps of torque.
7	Cylinder head gasket	1	Reverse the removal steps for installation.

## SERVICE POINTS


## Cylinder head inspection

## 1. Inspect:

- Water jacket  
Material deposit/Corrosion → Clean.
- Cylinder inner surface  
Score marks → Clean.  
Use #600 ~ 800 grit wet sandpaper.

**CAUTION:**

Do not scratch the mating surfaces of the cylinder head and cylinder body.




## 2. Measure:

- Cylinder head warpage  
Use a straightedge and feeler gauge.  
Out of specification → Rebore or replace.



**Warpage limit:**  
0.1 mm (0.004 in)

**Resurfacing steps:**

- Place a 400 ~ 600 grit wet sandpaper on the surface plate.
- Resurface the head using a figure-eight sanding pattern.



**NOTE:**

Rotate the head several times to avoid removing too much material from one side.



## CRANKCASE AND CYLINDER BODY EXPLODED DIAGRAM

1st	5 Nm (0.5 m·kg, 3.6 ft·lb)
2nd	10 Nm(1.0 m·kg, 7.2 ft·lb)





## REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	<b>CRANKCASE AND CYLINDER BODY REMOVAL</b>		Follow the left "Step" for removal.
	Power unit		Refer to "POWER UNIT REMOVAL".
	Magneto base assembly		Refer to "FLYWHEEL MAGNETO AND MAGNETO BASE".
	Reed valve		Refer to "REED VALVE".
	Cylinder head		Refer to "CYLINDER HEAD".
1	Clip	2	
2	Drain less hose	1	
3	Bolt (with washer)	2	6 x 40 mm
4	Clamp	1	
5	Crankcase	1	
6	Cylinder body	1	<b>NOTE:</b> _____ Film-coat the crankcase mating surface with Gasket Maker or equivalent.
7	Dowel pin	2	_____
8	Check valve	1	
9	Hose joint	2	
10	Taper plug	1	
			Reverse the removal steps for installation.

## SERVICE POINTS

## Cylinder body inspection

## 1. Inspect:


- Water jacket  
Material deposit/Corrosion → Clean.
- Cylinder inner surface  
Score marks → Clean.  
Use #600 ~ 800 grit wet sandpaper.

**CAUTION:** \_\_\_\_\_

**Do not scratch the fitting surfaces of the crankcase and cylinder body.**

## 2. Inspect:

- Exhaust wall  
Crack/Damage → Replace.  
Carbon deposit → Clean.  
Use a round scraper.



## 3. Measure:


•Cylinder bore "D"

Use cylinder gauge.

Out of specification → Rebore or replace.

## NOTE: \_\_\_\_\_

Measure the cylinder bore in parallel. Then, find the average of the measurement.



## Cylinder bore:

2B 39.00 ~ 39.02 mm  
(1.535 ~ 1.536 in)2C 42.00 ~ 42.02 mm  
(1.654 ~ 1.654 in)

## Wear limit:


2B 39.10 mm (1.54 in)  
2C 42.10 mm (1.66 in)

## Taper limit "T":

0.08 mm (0.003 in)

## Out of round limit :

0.05 mm (0.002 in)




**D** = Maximum Dia. (D1 ~ D6)  
**T** = (Maximum D1 or D2) - (minimum D5 or D6)

A: 10 mm (0.4 in) below the cylinder top

B: 5 mm (0.2 in) above the exhaust port

C: 5 mm (0.2 in) below the scavenging port



## Piston to cylinder clearance

## 1. Calculate:

•Piston clearance

Out of specification → Replace piston and piston ring and/or cylinder.

$$\text{Piston clearance} = \boxed{\text{Cylinder bore}} - \boxed{\text{Piston diameter}}$$



## Piston clearance:

0.030 ~ 0.035 mm  
(0.0012 ~ 0.0014 in)

## Limit:

0.085 mm (0.0033 in)

**Cylinder body and crankcase installation**

## 1. Install:

- Cylinder body
- Crankshaft and piston

**NOTE: \_\_\_\_\_**


- Align the piston ring end gaps with the respective locating pins.
- Fit the bearing locating pins in the cylinder body.


## 2. Apply:

- Gasket maker  
Onto the mating surfaces of the crankcase and cylinder body.

**NOTE: \_\_\_\_\_**

- Clean the mating surfaces of the crankcase and cylinder body before applying the Gasket maker.
- Gasket maker should be so applied that it does not overflow the mating surface.



**CRANKSHAFT AND PISTON  
EXPLODED DIAGRAM**



## REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	<b>CRANKSHAFT AND PISTON REMOVAL</b>		Follow the left "Step" for removal.
	Crankcase		Refer to "CRANKCASE AND CYLINDER BODY".
1	Crankshaft assembly	1	<b>NOTE:</b> Remove the crankshaft by lightly tapping it with a plastic hammer.
2	Oil seal	1	
3	Oil seal	1	
4	Plane washer	1	
5	Piston pin clip	2	<b>CAUTION:</b> Always use the new clip.
6	Piston pin	1	
7	Small end bearing	1	
8	Piston	1	<b>NOTE:</b> Align the "UP" mark on the piston crown towards the crankshaft tapered end.
9	Piston ring	2	<b>NOTE:</b> Remove the piston ring from the piston by opening the ring to the least possible width.
10	Bearing	2	<b>CAUTION:</b> When installing the bearing, the seal-cap side should be installed towards the flywheel side.
			Reverse the removal steps for installation.

## SERVICE POINTS


## Bearing removal

## 1. Remove:


- Bearing

**NOTE:**

Hold the bearing with the bearing separator, and forth out the crankshaft with a press.



**Bearing separator:**  
YB-06219 / 90890-06534



### Piston inspection

#### 1. Measure:

- Piston diameter "D"
- Use a micrometer.
- Out of specification → Replace.



#### Piston diameter:

2B: 38.967 ~ 38.986 mm

(1.5341 ~ 1.5349 in)

2C: 41.970 ~ 42.000 mm

(1.6524 ~ 1.6535 in)

#### Measuring point "H":

10 mm (0.39 in)

#### Oversize piston diameter:

2B 1\*: 39.25 mm (1.545 in)\*

2 : 39.50 mm (1.555 in)

2C 1: 42.25 mm (1.663 in)

2 : 42.50 mm (1.673 in)

\* : Except for U.S.A.

#### 2. Measure:

- Piston pin boss inside diameter

Use a micrometer.


Out of specification → Replace.



#### Piston pin boss inside diameter:

10.004 ~ 10.015 mm


(0.3939 ~ 0.3943 in)



### Piston pin and small end bearing inspection

#### 1. Inspect:

- Piston pin
- Small end bearing
- Signs of heat discoloration → Replace.
- Scratch/Damage → Replace.



#### 2. Measure:

- Piston pin diameter

Use a micrometer.


Out of specification → Replace.



#### Piston pin diameter:

9.996 ~ 10.000 mm


(0.3935 ~ 0.3937 in)



## 3. Check:

- Free play (when the piston pin is inserted in the piston.)

There should be no noticeable free play.  
Free play exists → Replace the pin and/or piston.



## Piston ring inspection

## 1. Inspect:

- Piston ring

Break/Damage → Replace.

## 2. Measure:

- End gap

Use a thickness gauge.

Out of specification → Replace.




## End gap:

**Top** 0.10 ~ 0.30 mm  
(0.004 ~ 0.012 in)

**2nd** 0.10 ~ 0.30 mm  
(0.004 ~ 0.012 in)

**Measuring point "H":**  
20 mm (0.8 in)



## NOTE: \_\_\_\_\_

Install the piston ring into the cylinder. Push the ring with the piston crown.

## 3. Measure:

- Side clearance

Use a thickness gauge.

Out of specification → Replace piston and/or ring.



## Side clearance:

**2B** **Top:** 0.03 ~ 0.07 mm  
**B** (0.001 ~ 0.003 in)


**2nd:** 0.03 ~ 0.07 mm



**B** (0.001 ~ 0.003 in)

**2C** **Top:** 0.02 ~ 0.06 mm  
**A** (0.001 ~ 0.002 in)

**2nd:** 0.03 ~ 0.07 mm

**B** (0.001 ~ 0.003 in)





### Crankshaft inspection

#### 1. Measure:



- Crank width "A"
- Big end side clearance "E"

Out of specification → Replace.



**Crank width:**  
27.90 ~ 27.95 mm  
(1.098 ~ 1.100 in)

**Big end side clearance:**  
0.30 ~ 0.60 mm  
(0.012 ~ 0.024 in)




#### 2. Measure:

- Runout "D"

Use a V-blocks and dial gauge.  
Out of specification → Replace.



**Runout limit:**  
0.02 mm (0.001 in)




#### 3. Measure:

- Small end axial play "F"

Out of specification → Replace.



**Small end axial play limit:**  
2.0 mm (0.08 in)





#### 4. Inspect:

- Crankshaft bearing

Pitting/ Rumbling → Replace.

### CAUTION:

Do not spin bearing with air blower; this can damage the bearing.



### Piston and piston ring installation

#### 1. Install:

- Piston ring (2nd)
- Piston ring (top)


#### CAUTION:

- Align the each ring end gap with their locating pins.
- After mating the rings, check that they move smoothly.



## CHAPTER 6 LOWER UNIT

<b>LOWER UNIT AND PROPELLER</b> .....	6-1
EXPLODED DIAGRAM .....	6-1
REMOVAL AND INSTALLATION CHART .....	6-2
SERVICE POINTS .....	6-2
Pipe inspection .....	6-2
Cotter pin and shear pin inspection .....	6-2
Propeller inspection .....	6-2
 <b>PINION GEAR, WATER PUMP AND FORWARD GEAR</b> .....	6-3
EXPLODED DIAGRAM .....	6-3
REMOVAL AND INSTALLATION CHART .....	6-4
SERVICE POINTS .....	6-5
Lower case cap inspection .....	6-5
Pinion gear inspection .....	6-5
Drive shaft inspection .....	6-5
Insert cartridge and impeller inspection .....	6-5
Water pump housing cover inspection .....	6-5
Forward gear inspection .....	6-5
 <b>LOWER CASE</b> .....	6-6
EXPLODED DIAGRAM .....	6-6
REMOVAL AND INSTALLATION CHART .....	6-7
SERVICE POINTS .....	6-7
Forward gear bearing removal .....	6-7
Drive shaft bushing removal .....	6-7
Bearing inspection .....	6-8
Lower case inspection .....	6-8
Drive shaft bushing installation .....	6-8
 <b>SHIMMING</b> .....	6-9
BACKLASH MEASUREMENT .....	6-9
Forward gear backlash .....	6-9

**LOWR****LOWER UNIT AND PROPELLER****E****LOWER UNIT AND PROPELLER  
EXPLODED DIAGRAM**

LOWR



## LOWER UNIT AND PROPELLER

E

### REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	<b>LOWER UNIT REMOVAL</b>		Follow the left "Step" for removal.
1	Bolt (with washer)	2	6 x 30mm
2	Lower unit	1	
3	Pipe	1	
4	Plate	1	
5	Dowel pin	2	
	<b>PROPELLER REMOVAL</b>		
6	Cotter pin	1	
7	Propeller	1	
8	Straight pin	1	
			Reverse the removal steps for installation.

### SERVICE POINTS

#### Pipe inspection

1. Inspect:
  - Pipe
 Wear/Crack/Damage → Replace.

#### Cotter pin and shear pin inspection

1. Inspect:
  - Cotter pin
  - Shear pin
 Wear/Damage → Replace.

#### Propeller inspection


1. Inspect:
  - Blade
 Wear/Crack/Damage → Replace.

LOWR



## PINION GEAR, WATER PUMP AND FORWARD GEAR

E

PINION GEAR, WATER PUMP AND FORWARD GEAR  
EXPLODED DIAGRAM

LOWR



## PINION GEAR, WATER PUMP AND FORWARD GEAR

E

## REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	<b>PINION GEAR, WATER PUMP AND FORWARD GEAR REMOVAL</b>		Follow the left "Step" for removal. Step
	Gear oil		Refer to "LOWER UNIT" section in chapter 3.
	Lower unit		Refer to "LOWER UNIT AND PROPELLER".
	Propeller		Refer to "LOWER UNIT AND PROPELLER".
1	Bolt (with washer)	2	6 x 14mm
2	Lower case cap	1	
3	O-ring	1	
4	Oil seal	1	
5	Circlip	1	
6	Pinion gear	1	
7	Plane washer	1	
8	Pinion gear shim	1	
9	Bolt (with washer)	2	5 x 16mm
10	Drive shaft	1	
11	Oil seal protector	1	
12	Insert cartridge	1	<b>NOTE:</b> When installing the water pump housing, align the hole in it with the projection in the insert cartridge.
13	Impeller	1	<b>NOTE:</b> When installing the impeller, turn the drive shaft clockwise.
14	Dowel pin	1	
15	Cartridge outer plate	1	
16	Water pump housing cover	1	
17	Oil seal	2	
18	O-ring	1	
19	Dowel pin	2	
20	Water seal	1	
21	Forward gear	1	
22	Forward gear shim	1	
			Reverse the removal steps for installation.

**SERVICE POINTS****Lower case cap inspection**

1. Clean:
  - Lower case capUse a soft brush and solvent.
2. Inspect:
  - Lower case capCrack/Damage → Replace.

**Pinion gear inspection**

1. Inspect:
  - TeethWear/Damage → Replace.

**Drive shaft inspection**

1. Inspect:
  - Drive shaftWear/Damage → Replace.

**Insert cartridge and impeller inspection**

1. Inspect:
  - Insert cartridge
  - ImpellerCrack/Damage → Replace.

**Water pump housing cover inspection**

1. Inspect:
  - Water pump housing coverCrack/Damage → Replace.

**Forward gear inspection**


1. Inspect:
  - Teeth
  - ShaftWear/Damage → Replace.

LOWR



PINION GEAR, WATER PUMP AND FORWARD GEAR

E


**LOWR****LOWER CASE****E****LOWER CASE  
EXPLODED DIAGRAM**




## REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	<b>LOWER CASE DISASSEMBLY</b>		Follow the left "Step" for removal.
	Lower unit		Refer to "LOWER UNIT AND PROPELLER".
	Forward gear		Refer to "PINION GEAR, WATER PUMP AND FORWARD GEAR".
1	Bolt	1	6 x 12 mm
2	Toothed washer	1	
3	Anode	1	
4	Bearing	1	
5	Oil seal	1	
6	Drive shaft bushing	1	
7	Drive shaft bushing	1	
8	Drive shaft bushing	1	
9	Lower case	1	
Reverse the removal steps for installation.			

A



B



## SERVICE POINTS

## Forward gear bearing removal

1. Remove:
  - Forward gear bearing

**Slide hammer set:****YB-06096****Stopper guide plate:****90890-06501****Bearing outer race puller claw:****90890-06535****Stopper guide stand:****90890-06538****[A] For USA and CANADA****[B] Except for USA and CANADA**

## Drive shaft bushing removal

1. Remove:
  - Drive shaft bushing

**Drive shaft bushing remover:****YB-06027/90890-06651****Driver rod:****YB-06229/90890-06652**




### Bearing inspection

1. Inspect:
  - Bearing
  - Pitting/Rumbling → Replace.

### Lower case inspection

1. Clean:
  - Gear case
  - Use a soft brush and solvent.
2. Inspect:
  - Water passage
  - Mineral deposits/Corrosion → Clean.
3. Inspect:
  - Lower case
  - Crack/Damage → Replace.



### Drive shaft bushing installation

1. Install:
  - Drive shaft bushing




**Bearing installer:**

**YB-06027/90890-06651**

**Driver rod:**

**YB-06229/90890-06652**



2. Install:

- Drive shaft bushing



**Bushing installer:**


**YB-06029/90890-06601**

**Needle bearing installer:**

**YB-06169**

**Bushing attachment:**

**90890-06651**



**A** For USA and CANADA

**B** Except for USA and CANADA



## SHIMMING BACKLASH MEASUREMENT

### NOTE: \_\_\_\_\_

Do not install the water pump components when measuring the backlash.

### Forward gear backlash


#### 1. Measure:

- Forward gear backlash  
Out of specification → Adjust.



#### Backlash:

0.27~0.99mm



#### Measuring steps:

- Attach the backlash indicator on the drive shaft (11 mm in diameter).



#### Backlash indicator:

YB-06265/90890-06265

- Attach the dial gauge on the gear case, and make the dial gauge stem contact the mark on the indicator.



#### Backlash adjusting plate:

YB-07003

#### Dial gauge:

YU-03097/90890-01252

#### Magnetic flexible stand:

YU-34481/90890-06705

- While pulling the drive shaft and pushing the propeller shaft, slowly turn the drive shaft clockwise and counterclockwise; then, measure the backlash when the drive shaft stops in each direction.

**LOWR****SHIMMING****E****2. Adjust:**

- Forward gear shim

**NOTE: \_\_\_\_\_**

Adjust the shim to be added or removed according to specification.

	<b>Forward gear backlash</b>	<b>Shim thickness</b>
	<b>Less than 0.27 mm</b>	<b>To be decreased by (0.63 - measurement) <math>\times 0.47</math></b>
	<b>More than 0.99 mm</b>	<b>To be increased by (measurement - 0.63) <math>\times 0.47</math></b>
<b>Available shim thickness: 0.30, 0.40 and 0.50 mm</b>		



## CHAPTER 7 BRACKET UNIT


<b>UPPER CASE AND TILLER HANDLE .....</b>	7-1
EXPLDED DIAGRAM .....	7-1
REMOVAL AND INSTALLATION CHART .....	7-2
SERVICE POINTS .....	7-2
Pivot shaft bushing inspection .....	7-2
Tiller handle inspection .....	7-2
 <b>CLAMP BRACKET .....</b>	7-3
EXPLDED DIAGRAM .....	7-3
REMOVAL AND INSTALLATION CHART .....	7-4

BRKT



## UPPER CASE AND TILLER HANDLE

E

UPPER CASE AND TILLER HANDLE  
EXPLODED DIAGRAM



## REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	<b>UPPER CASE REMOVAL</b>		Follow the left "Step" for removal.
	Power unit		Refer to "POWER UNIT REMOVAL" section in chapter 5.
	Lower unit		Refer to "LOWER UNIT AND PROPELLER" section in chapter 6.
1	Exhaust guide	1	
2	O-ring	1	
3	Exhaust guide gasket	1	
4	Water tube	1	
5	Water seal	1	
6	Bolt (with washer)	4	
7	Nut	4	
8	Swivel bracket holder	1	
9	Pivot shaft bushing	2	
10	Upper case	1	
11	O-ring	1	
12	Screw (with washer)	1	
13	Upper case cover	1	
14	Upper case cover gasket	1	
	<b>TILLER HANDLE REMOVAL</b>		
15	Nut	1	
16	Bolt	1	
17	Copper washer	1	
18	Tiller handle assembly	1	
19	Copper washer	1	
20	Plane washer	1	
21	Spring washer	1	
22	Bolt (with washer)	1	
23	Plate	1	
24	Handle grip	1	
25	Shear pin holder	1	
			Reverse the removal steps for installation.

## SERVICE POINTS

## Pivot shaft bushing inspection

## 1. Inspect:

- Pivot shaft bushing
- Wear/Crack/Damage → Replace.

## Tiller handle inspection

## 1. Inspect:


- Tiller handle
- Wear/Crack/Damage → Replace.

BRKT



CLAMP BRACKET

E

**CLAMP BRACKET  
EXPLODED DIAGRAM**

BRKT



CLAMP BRACKET

E

## REMOVAL AND INSTALLATION CHART

Step	Procedure/Part name	Q'ty	Service points
	<b>CLAMP BRACKET REMOVAL</b>		Follow the left "Step" for removal.
	Upper case assembly		Refer to "UPPER CASE AND TILLER HANDLE"
1	Spring pin	1	
2	Wing nut	1	
3	Plane washer	1	
4	Bolt	1	
5	Nut	1	
6	Clamp bracket plate	1	
7	Clamp bracket RH	1	
8	Thrust bracket	1	
9	Plane washer	1	
10	Swivel bracket	1	
11	Plane washer	1	
12	Clamp bracket LH	1	
13	Bolt	2	
Reverse the removal steps for installation.			




## CHAPTER 8 ELECTRICAL SYSTEM

ELECTRICAL COMPONENTS .....	8-1
ELECTRICAL ANALYSIS .....	8-2
INSPECTION .....	8-2
Low resistance measurement.....	8-2
IGNITION SYSTEM .....	8-3
IGNITION SPARK GAP .....	8-4
SPARK PLUG .....	8-5
SPARK PLUG CAP .....	8-5
IGNITION COIL.....	8-6
STOP SWITCH .....	8-6
CHARGE COIL .....	8-7
CDI UNIT .....	8-7

**ELECTRICAL COMPONENTS**

- ① CDI unit
- ② Ignition coil

B : Black  
Br : Brown  
O : Orange  
W : White





## ELECTRICAL ANALYSIS INSPECTION

### CAUTION:

All measuring instruments should be handled with special care, or the correct measurement is impossible.

On an instrument powered by dry batteries, they should be checked for voltage periodically and replaced, if necessary.

### NOTE:

"O---O" indicates the terminals between which there is a continuity of electricity; i.e., a closed circuit at the respective switch position.

### Low resistance measurement

When measuring the resistance of  $10\ \Omega$  or less using the digital tester, the correct measurement cannot be obtained because of the tester's internal resistance.

To obtain the correct value, subtract this internal resistance from the displayed measurement.




Correct value =  
Displayed measurement - Internal  
resistance

### NOTE:


The internal resistance of the tester can be obtained by connecting both of its terminals.

## IGNITION SYSTEM



- ① Ignition coil
- ② Charge coil
- ③ Stop switch
- ④ CDI unit


- B : Black
- Br : Brown
- O : Orange
- W : White



## IGNITION SPARK GAP

### ⚠ WARNING

- While taking spark check be careful not to touch any connection of lead wires of the 'Ignition spark gap tester'.
- When doing the spark test, take special care not to allow leakage from the removed plug cap.
- This check is likely to produce sparks, so be sure that no flammable gas or fluid is in the vicinity.



### 1. Check:

- Ignition spark gap  
Out of specification → Replace.



**Spark gap:**  
9 mm (0.35 in)




### Checking steps:


- Adjust the spark gap to specification by turning the adjusting knob.



**Spark gap tester:**  
YM-34487/90890-06754

- Connect the spark-plug cap to the spark gap tester.
- Remove the spark plug from the engine.
- Cranking the engine and check sparks of ignition system seen through discharge window.









## SPARK PLUG

Refer to "GENERAL" section in chapter 3.

## SPARK PLUG CAP

## 1. Inspect:

- Spark plug cap  
Loosen → Tighten.  
Crack/Damage → Replace.



## **Replacement steps: (Except for Canada and Europe)**

- Remove the spark-plug cap by pulling the spark-plug cap.
- Remove the plug-cap spring.
- Strip the insulation cover 5 mm (0.2 in)  and spread the core wires outward.
- Fit the plug-cap spring close to the spread core wires and bend the spring end for clamping.
- Install the plug-cap spring into the spark-plug cap.

## **Replacement steps: (For Canada and Europe)**

- Remove the spark-plug cap by turning the cap counterclockwise.
- Install the spark-plug cap by turning the cap clockwise until it stops.



## IGNITION COIL

### 1. Inspect:

- High tension cord
- Crsck/Damage → Replace.

### 2. Measure:



- Secondary coil resistance
- Out of specification → Replace.



**Primary coil resistance :**  
Orange (O) - Black (B)  
0.18 ~ 0.24 Ω at 20°C (68°F)

### NOTE:

When measuring the resistance of 10 Ω or less using the digital tester, the correct measurement cannot be obtained. Refer to "Lower resistance measurement".



### 3. Measure:

- Secondary coil resistance
- Out of specification → Replace.



**Secondary coil resistance :**  
Orange (O) - High tension cord  
2.7 ~ 3.7 kΩ at 20°C (68°F)

### NOTE:

Remove the spark-plug cap from high tension cord.

## STOP SWITCH

### 1. Check:



- Continuity
- Out of specification → Replace.



Checking leads color  
White (W) - Black (B)

Free  
Push the button

Discontinuity  
Continuity



## CHARGE COIL

### 1. Measure:

- Charge coil resistance
- Out of specification → Replace.



**Charge coil resistance:**

**Brown (Br) - Earth**

**316.8 ~ 387.2 Ω at 20 °C (68°F)**

## CDI UNIT

### 1. Measure:

- CDI unit resistance
- Out of specification → Replace.



**Pocket tester**

**YU-03112/90890-03112**

### NOTE: \_\_\_\_\_

- The resistance values will vary from meter to meter, especially with electronic digital meters. For some testers, polarity of leads is reversed.
- “•” indicates that the pointer deflects once and returns to specification.
- “∞” mark indicates discontinuity.

Unit: kΩ				
(-)	(+)	W	B	Br
W		•	∞	•
B	2.2~9.5		2.2~9.5	•
Br	∞	•		•
0	7~30	2~9	7~30	

## CHAPTER 9 TROUBLE ANALYSIS

TROUBLE ANALYSIS .....	9-1
TROUBLE ANALYSIS CHART .....	9-1

## TROUBLE ANALYSIS

NOTE: \_\_\_\_\_

Following items should be obtained before "trouble analysis".

1. There is no incorrect wiring connection.
2. Wiring connections are surely engaged and without any rust.

## TROUBLE ANALYSIS CHART

Trouble mode						Check elements		Reference Chapter
ENGINE WILL NOT START	ROUGH IDLING	ENGINE STALLS	ENGINE WILL NOT STOP	POOR PERFORMANCE	OVERHEATING	LOOSE STEERING	Relative part	
FUEL SYSTEM								
O	O	O	O				Carburetor	4
	O	O					Idle speed	3
POWER UNIT								
O	O		O				Compression	5
O	O		O				Reed valve	5
O	O						Cylinder head gasket	5
O			O				Piston ring	5
O			O				Cylinder block	5
O			O				Seal	5
O			O				Crankcase	5
O							Piston	5
			O				Bearing	5
				O			Water passage	5
LOWER UNIT								
O							Gear	6
			O	O			Water inlet	6
			O	O			Water pump	6
			O				Propeller shaft	6
							Lower case	6
BRACKET UNIT								
			O				Bracket	7
ELECTRICAL								
O	O	O	O	O	O		Ignition system	8

DO NOT REMOVE THIS ITEM FROM  
THE YAMAHA LIBRARY!

4/25/2000

LIBRARY COPY

**LIT-18616-01-31**



**2(U-V) 1996 Service Manual**

**YAMAHA**

YAMAHA MOTOR CO., LTD.

Printed in Japan

Jun. 1995 - 0.8 x 1 CR

**6A1-28197-Z5-11**

(2B, 2C)

(英)

Printed on recycled paper